

IN-LB

Inch-Pound Units

SI

International System of Units

Guide to Hot Weather Concreting

Reported by ACI Committee 305

ACI 305R-20



American Concrete Institute
Always advancing

This is a preview. [Click here to purchase the full publication.](#)



Guide to Hot Weather Concreting

Copyright by the American Concrete Institute, Farmington Hills, MI. All rights reserved. This material may not be reproduced or copied, in whole or part, in any printed, mechanical, electronic, film, or other distribution and storage media, without the written consent of ACI.

The technical committees responsible for ACI committee reports and standards strive to avoid ambiguities, omissions, and errors in these documents. In spite of these efforts, the users of ACI documents occasionally find information or requirements that may be subject to more than one interpretation or may be incomplete or incorrect. Users who have suggestions for the improvement of ACI documents are requested to contact ACI via the errata website at <http://concrete.org/Publications/DocumentErrata.aspx>. Proper use of this document includes periodically checking for errata for the most up-to-date revisions.

ACI committee documents are intended for the use of individuals who are competent to evaluate the significance and limitations of its content and recommendations and who will accept responsibility for the application of the material it contains. Individuals who use this publication in any way assume all risk and accept total responsibility for the application and use of this information.

All information in this publication is provided “as is” without warranty of any kind, either express or implied, including but not limited to, the implied warranties of merchantability, fitness for a particular purpose or non-infringement.

ACI and its members disclaim liability for damages of any kind, including any special, indirect, incidental, or consequential damages, including without limitation, lost revenues or lost profits, which may result from the use of this publication.

It is the responsibility of the user of this document to establish health and safety practices appropriate to the specific circumstances involved with its use. ACI does not make any representations with regard to health and safety issues and the use of this document. The user must determine the applicability of all regulatory limitations before applying the document and must comply with all applicable laws and regulations, including but not limited to, United States Occupational Safety and Health Administration (OSHA) health and safety standards.

Participation by governmental representatives in the work of the American Concrete Institute and in the development of Institute standards does not constitute governmental endorsement of ACI or the standards that it develops.

Order information: ACI documents are available in print, by download, through electronic subscription, or reprint and may be obtained by contacting ACI.

Most ACI standards and committee reports are gathered together in the annually revised the ACI Collection of Concrete Codes, Specifications, and Practices.

American Concrete Institute
38800 Country Club Drive
Farmington Hills, MI 48331
Phone: +1.248.848.3700
Fax: +1.248.848.3701

www.concrete.org

Guide to Hot Weather Concreting

Reported by ACI Committee 305

Oscar R. Antommattei, Chair

Chad B. Hensley, Secretary

James M. Aldred
Godwin Q. Amekuedi
Mehdi Bakhshi
Philip Brandt
Kirk K. Deadrick
Michael S. Faubel

Antonio J. Guerra
G. Terry Harris
T. J. Harris
Kenneth C. Hover
Tarek S. Khan
Frank A. Kozeliski

Darmawan Ludirdja
Quinn McGuire
David R. Nau
William D. Palmer
Jonathan L. Poole
Jorge L. Quiros

Bruce G. Smith
William W. Squyres
Boris Y. Stein
Diep T. Tu

Consulting Members

James N. Cornell

D. Gene Daniel*

George V. Teodoru

*Deceased.

Environmental factors, such as high ambient temperature, low humidity, high wind, or both low humidity and high wind, affect concrete properties and the construction operations of mixing, transporting, and placing of the concrete materials. This guide provides measures that can be taken to minimize the undesirable effects of these environmental factors and reduce the potential for serious problems.

This guide defines hot weather, discusses potential problems, and presents practices intended to minimize them. These practices include selecting materials and proportions, precooling ingredients, and batching. Other topics discussed include length of haul, consideration of concrete temperature as placed, facilities for handling concrete at the site, and, during the early curing period, placing and curing techniques, and appropriate testing and inspection procedures in hot weather conditions.

The materials, processes, quality control measures, and inspections described in this document should be tested, monitored, or performed as applicable only by individuals holding the appropriate ACI certifications or equivalent.

Keywords: air entrainment; cooling; curing; evaporation; high temperature; hot weather construction; plastic shrinkage; production methods; retempering; slump tests; water content.

ACI Committee Reports, Guides, and Commentaries are intended for guidance in planning, designing, executing, and inspecting construction. This document is intended for the use of individuals who are competent to evaluate the significance and limitations of its content and recommendations and who will accept responsibility for the application of the material it contains. The American Concrete Institute disclaims any and all responsibility for the stated principles. The Institute shall not be liable for any loss or damage arising therefrom.

Reference to this document shall not be made in contract documents. If items found in this document are desired by the Architect/Engineer to be a part of the contract documents, they shall be restated in mandatory language for incorporation by the Architect/Engineer.

CONTENTS

CHAPTER 1—INTRODUCTION AND SCOPE, p. 2

1.1—Introduction, p. 2

1.2—Scope, p. 2

CHAPTER 2—NOTATION AND DEFINITIONS, p. 2

2.1—Notation, p. 2

2.2—Definitions, p. 3

CHAPTER 3—POTENTIAL PROBLEMS AND PRACTICES, p. 3

3.1—Potential problems in hot weather, p. 3

3.2—Potential problems related to other factors, p. 3

3.3—Practices for hot weather concreting, p. 3

CHAPTER 4—EFFECTS OF HOT WEATHER ON CONCRETE PROPERTIES, p. 4

4.1—General, p. 4

4.2—Calculating estimated evaporation rate, p. 7

4.3—Effects of temperature of concrete, p. 9

4.4—Maximum ambient and concrete temperature, p. 9

4.5—Water, p. 10

4.6—Cement, p. 11

4.7—Supplementary cementitious materials, p. 12

4.8—Chemical admixtures, p. 12

4.9—Aggregates, p. 14

4.10—Fibers, p. 14

4.11—Proportioning, p. 15

ACI 305R-20 was adopted and published September 2020.

Copyright © 2020, American Concrete Institute.

All rights reserved including rights of reproduction and use in any form or by any means, including the making of copies by any photo process, or by electronic or mechanical device, printed, written, or oral, or recording for sound or visual reproduction or for use in any knowledge or retrieval system or device, unless permission in writing is granted by the American Concrete Institute.

CHAPTER 5—PRODUCTION AND DELIVERY, p. 16

- 5.1—General, p. 16
- 5.2—Temperature control of concrete, p. 16
- 5.3—Batching and mixing, p. 17
- 5.4—Delivery, p. 18
- 5.5—Slump adjustment, p. 18
- 5.6—Properties of concrete mixtures, p. 18
- 5.7—Retempering, p. 18

CHAPTER 6—PLACING AND CURING, p. 18

- 6.1—General, p. 18
- 6.2—Preparations for placing and curing, p. 18
- 6.3—Placement and finishing, p. 19
- 6.4—Curing and protection, p. 20

CHAPTER 7—TESTING AND INSPECTION, p. 21

- 7.1—Testing, p. 21
- 7.2—Inspection, p. 21

CHAPTER 8—REFERENCES, p. 22

- 8.1—Referenced standards and reports, p. 22
- 8.2—Cited references, p. 23

APPENDIX A—ESTIMATING CONCRETE TEMPERATURE, p. 25

- A.1—Estimating temperature of freshly mixed concrete, p. 25
- A.2—Estimating temperature of concrete with ice, p. 25

APPENDIX B—METHODS FOR COOLING FRESH CONCRETE, p. 25

- B.1—Cooling with chilled mixing water, p. 25
- B.2—Liquid nitrogen cooling of mixing water, p. 25
- B.3—Cooling concrete with ice, p. 25
- B.4—Cooling mixed concrete with liquid nitrogen, p. 26
- B.5—Cooling of coarse aggregates, p. 26

CHAPTER 1—INTRODUCTION AND SCOPE**1.1—Introduction**

Hot weather can create problems in delivery, mixing, placing, and curing hydraulic-cement concrete that can adversely affect the properties and serviceability of the concrete. Most of these problems relate to the increased rate of cement hydration at higher temperature and increased evaporation rate of moisture from the freshly mixed concrete. The rate of cement hydration depends on ambient and concrete temperature, cement composition and fineness, amount and type of supplementary cementitious materials, and admixtures used.

A maximum as-placed concrete temperature is often specified in an effort to control rate of setting, strength, durability, plastic shrinkage cracking, thermal cracking, and drying shrinkage. The placement of concrete in hot weather, however, is too complex to be dealt with by just setting a maximum as-placed or as-delivered concrete temperature. Concrete durability is defined as the ability of concrete to resist weathering action, chemical attack, abrasion, or any

other process of deterioration (ACI 201.2R). Generally, if concrete strengths are satisfactory and curing practices are sufficient to avoid undesirable drying of surfaces, the durability of hot weather concrete will not differ greatly from similar concrete placed at normal temperatures.

Where an acceptable record of field tests is not available, concrete proportions can be determined by trial batches (ACI 301 and 211.1). Trial batches should be made at temperatures anticipated in the work and mixed following one of the procedures described in 4.10. The concrete supplier is generally responsible for determining concrete proportions to produce the required quality of concrete unless specified otherwise.

If the initial 24-hour curing is at 100°F (38°C), the 28-day compressive strength of the test specimens may be 10 to 15 percent lower than if cured at the required ASTM C31/C31M curing temperature (Gaynor et al. 1985). If the cylinders are allowed to dry at early ages, strengths will be reduced even further (Cebeci 1987). Therefore, proper curing of the test specimens during hot weather is critical, and steps should be taken to ensure that the specified procedures are followed.

The effects of high air temperature and low relative humidity are more pronounced with increases in wind speed. The potential problems of hot weather concreting can occur at any time of the year, but generally occur during the summer season. Drying conditions can occur even at lower ambient temperatures, with slower set times, lower relative humidity, and wind, all of which are conducive to higher evaporation. Precautionary measures required on a windy, sunny day will be stricter than those required on a calm, humid day, even if air temperatures are identical.

1.2—Scope

This guide identifies problems associated with hot weather concreting and describes practices that alleviate these potential adverse effects. These practices include suggested preparations and procedures for use in general types of hot weather construction, such as pavements, bridges, and buildings either cast in place or precast. Temperature, volume changes, and cracking problems associated with mass concrete are treated more thoroughly in ACI 207.1R, 207.2R, and 224R.

CHAPTER 2—NOTATION AND DEFINITIONS**2.1—Notation**

E = evaporation rate, lb/ft²/h (kg/m²/h)

e_a = water vapor pressure in psi (mmHg) in the air surrounding the concrete obtained by multiplying the saturation vapor pressure at the temperature of the air surrounding the concrete by the relative humidity of the air. Air temperature and relative humidity are measured approximately 4 to 6 ft (1.2 to 1.8 m) above the concrete surface on the windward side and shielded from the sun's rays

e_o = saturation water vapor pressure in psi (mmHg) in the air immediately over the concrete surface, at the concrete temperature.

e_s = saturation vapor pressure, psi (kPa)

r = relative humidity, percent

T = temperature, °F (°C)
 T_a = air temperature, °F (°C)
 T_c = concrete (water surface) temperature, °F (°C)
 V = average wind speed in mph (km/h), measured at 20 in. (0.5 m) above the concrete surface
 W = mass of water evaporated in lb/ft² (kg/m²) of water-covered surface per hour

2.2—Definitions

Refer to the latest version of ACI Concrete Terminology for a comprehensive list of definitions. Definitions provided herein complement that resource.

hot weather—one or a combination of the following conditions that tends to impair the quality of freshly mixed or hardened concrete by accelerating the rate of moisture loss and rate of cement hydration, or otherwise causing detrimental results: high ambient temperature; high concrete temperature; low relative humidity; and high wind speed.

CHAPTER 3—POTENTIAL PROBLEMS AND PRACTICES

3.1—Potential problems in hot weather

Potential problems for concrete in the freshly mixed state include:

- a) Increased water demand
- b) Increased rate of slump loss and corresponding tendency to add water at the job site
- c) Increased rate of setting, resulting in greater difficulty with handling, compacting, and finishing, and a greater risk of cold joints
- d) Increased tendency for plastic shrinkage and thermal cracking
- e) Increased difficulty in controlling entrained air content

Damage to concrete caused by hot weather can never be fully alleviated. Potential deficiencies to concrete in the hardened state can include:

- a) Decreased strengths resulting from adding water to satisfy the higher water demand
- b) Increased tendency for drying shrinkage if additional water was added to the concrete
- c) Thermal cracking from either cooling of the overall structure, or from temperature differentials within the cross section of the member
- d) Decreased durability resulting from cracking
- e) Greater variability of surface appearance, such as cold joints or color differences, due to different rates of hydration or different water-cementitious materials ratios (w/cm)

3.2—Potential problems related to other factors

Other factors that should be considered along with climatic factors include:

- a) Cements with different and increased rate of hydration
- b) High-early-strength concrete, which may be proportioned with higher total cementitious content
- c) Thin concrete sections with correspondingly greater percentages of steel, which may complicate placing and consolidation of concrete

d) Economic necessity to continue work in extremely hot weather

e) Use of shrinkage-compensating cement

3.3—Practices for hot weather concreting

Good judgment is necessary to select procedures that appropriately blend quality, economy, and practicability. The procedures selected will depend on type of construction, characteristics of the materials being used, and the experience of the local industry in dealing with high ambient temperature, high concrete temperatures, low relative humidity, and high wind speed.

The most serious difficulties occur when personnel placing the concrete lack experience in constructing under hot weather conditions or in doing the specific type of construction. Last-minute improvisations are rarely successful. Early preventive measures should be applied with the emphasis on materials evaluation, advanced planning and purchasing, and coordination of all phases of work. Planning in advance for hot weather involves development of an appropriate concrete mixture and a detailed plan for mixing, transporting, placing, protecting, curing, and testing of concrete. Precautions to avoid plastic shrinkage cracking are important. The potential for thermal cracking, either from overall volume changes or from internal restraint, should be anticipated, properly assessed, and mitigated.

Typical methods to minimize and to limit crack size and spacing include: proper use and timely installation of joints; increased amounts of reinforcing steel; and practical limits on concrete temperature. Some adjustments to concrete mixtures that have been successful in hot weather conditions include: using a reduced cement content; using a low-heat-of-hydration cement; the selection and dosage of appropriate chemical admixtures; the use of supplementary cementitious materials to replace cement; and the use of synthetic microfibers and macrofibers.

Developing a comprehensive plan and procedures for use in hot weather concreting conditions include the following practices and measures used to reduce or avoid the potential problems of hot weather concreting, as discussed in detail in **Chapters 4 to 6**:

- a) Selecting concrete materials and proportions with satisfactory records in hot weather conditions or that have shown by testing to be satisfactory
- b) Reducing and controlling the temperature of fresh concrete
- c) Using a concrete mixture with sufficient workability that will permit rapid placement and effective consolidation
- d) Minimizing the time to transport, place, consolidate, and finish the concrete
- e) Scheduling of placing operations during times of the day or night when weather conditions are favorable
- f) Protecting the concrete from moisture loss during placing and curing periods
- g) Scheduling a preplacement conference to discuss the requirements of hot weather concreting

These suggestions are offered with the caveat that it may not be practical to implement any or all of them on a given