

The information and data contained in this document were prepared by a technical committee of the Association. The committee and the Association assume no liability or responsibility in connection with the use of such information or data, including but not limited to any liability under patent, copyright, or trade secret laws. The user is responsible for determining that this document is the most recent edition published.

Paper machine room ventilation guidelines

Scope

This Technical Information Paper provides an overview of principles and guidelines for designing and optimizing paper machine room ventilation systems.

Safety precautions

Normal safety precautions should be taken when working around operating machinery, hot surfaces, and steam systems.

Application note

This Technical Information Paper provides general descriptions and guidelines for designing air systems and estimating airflow requirements for machine room ventilation systems. Engineers with experience in paper machine room air handling should be consulted for specific design work and to address specific operating problems.

Calculations are presented in both English and SI units. Refer to Table 1 for English to metric conversions. Two sample calculations are included at end of the TIP; one for a linerboard paper machine and one for a copy grade paper machine.

Ventilation principles

Purpose and benefits

Ventilation air is used to improve drying uniformity and capacity, improve the working environment, reduce maintenance of roof and building equipment, reduce product contamination, and extend process equipment life. The amount of air required to produce a ton of paper can be 75 tons or more, depending on the grade of paper.

Ventilation air serves two primary purposes:

- contain and remove water vapor, heat, and dust
- replace air removed in the drying process and by vacuum systems

Ventilation systems can also cause unsafe conditions and impact production if not designed, operated, and maintained properly. A well ventilated building has the following attributes:

- good visibility (no fog) in the production areas
- no condensation on wall and ceiling surfaces

- comfort working conditions in operating areas
- no stagnant airflow areas
- controlled airflows in and out of the building for efficient paper drying and sheet handling
- energy efficiency

Contaminants

The three major contaminants present in a paper machine environment are water vapor, heat, and dust.

Water vapor

Uncontained water vapor will spread throughout the building primarily by convective air flows and, to a lesser degree, by diffusion.

Fog and condensation occur when the water partial pressure exceeds the equilibrium vapor pressure, which is dependent on the local temperature. The local temperature is a function of the heat gain or loss.

Heat

Papermaking is an energy intensive process. Typical process heat loads are listed as follows:

Area/Source	Floor Level	Heat	
		Btu/ton	kW-h/tonne
Stock Preparation			
- Refiners	Operating	73 900	19.6
Bleached Board:		37 000	9.8
Corrugating:		88 000	23.4
Fine Paper:		51 700	13.7
Linerboard:		59 100	15.7
Publication:			
- Cleaners (based on footprint)	Operating	1 000 Btu/h/ft ²	3.15 kW/m ²
- Pumps & Piping	Ground	20 000	5.3
Former & Press			
- Vacuum System	Ground	37 000	9.8
- Pumps & Piping	Ground	75 000	19.9
PM Drive			
- Forming & Press	Operating	51 600	13.7
- Main Dryer	Operating	18 500	4.9
- Size Press	Operating	3 200	0.9
- After Dryer	Operating	6 400	1.7
- Calender	Operating	14 500	3.9
- Coater	Operating	27 100	7.2
- Reel	Operating	8 600	2.3
- Winder	Operating	44 400	11.8

Dust

Airborne dust in high concentrations is an occupational health concern and can become a fuel source for fires.

The major sources of dust come from poor broke handling practices, sheet shedding doctor blades, and winder slitters. Sheet over-drying increases dusting.

Air lances, air nozzles, and air hoses should be avoided in cleaning dusty areas because they can cause dust to become airborne.

Dust prevention should be the primary focus, with cleaning and collection being the last steps.

Recommended levels

Minimum and maximum levels for temperature, humidity, and dust are recommended based on location within the machine room:

Variable	Location	Minimum	Maximum (above outdoor ambient)	Remarks
Temperature °F	Ground Floor	65	≤ 10	
	Operating Floor – tending, wet end	75	≤ 5	
	Operating Floor – tending, elsewhere	65	≤ 5	
	Operating Floor – drive side	65	≤ 10	
	Mezzanine	-	≤ 20	
	Underside Roof	-	≤ 25	
Humidity grains H ₂ O/lbDA	Ground and Operating Floors	-	≤ 50	No fog or condensation
	Mezzanine	-	≤ 100	
	Underside Roof	-	≤ 150	
Dust mg/m ³	Total (all airborne particles)	-	15 (including ambient)	
	Respirable (airborne particles <10 µm)	-	5 (including ambient)	

Factors affecting ventilation performance

The amount of ventilation air required is a function of a number of factors, including the following:

Factor	Impact on Building Ventilation
Production Rate	<ul style="list-style-type: none"> Higher production rates have higher evaporation rates and, correspondingly, require more air
Grade of Paper	<ul style="list-style-type: none"> Lighter grades are more susceptible to air drafts
Machine Speed	<ul style="list-style-type: none"> Higher heat and mass transfer with increased machine speed
Type of Former	<ul style="list-style-type: none"> Top wire and gap formers require higher exhaust rates than fourdrinier formers
Stock Temperature	<ul style="list-style-type: none"> Increase mass transfer rate with increase in temperature
Type and Condition of Dryer Hood	<ul style="list-style-type: none"> Open hood requires more exhaust air than a closed hood
Climate	<ul style="list-style-type: none"> Colder climates require higher building air balance Warmer climates require higher ventilation rates during the summer
Building Geometry	<ul style="list-style-type: none"> Air follows the path of least resistance leading to short-circuiting of air
Equipment Layout	<ul style="list-style-type: none"> Multiple machines in the same building are more difficult to ventilate than single-machine rooms
Building Construction	<ul style="list-style-type: none"> Building pressure is dependent on building tightness Increased risk of condensation with less wall and roof insulation

Air movement

Building air movement is a function of the air pressure, momentum, and density. The velocity of air discharged from a one-foot diameter opening drops to ten percent of its initial velocity within thirty feet from the opening. Stack effect causes cool and dry air to enter the building at the ground floor level as warm, moist (less dense) air rises to the underside of the roof, resulting in a vertical pressure difference with respect to the building exterior. With equal supply and exhaust flows, a neutral pressure level, or “null point”, would occur at or below the mezzanine floor level. Above the null point, air exfiltrate out (positive pressure) of the building and conversely infiltrate (negative pressure) into the building below the null point.

The dryer section hoods are greatly affected by stack effect. Increasing the hood exhaust or reducing the supply flow rates raises the null point. Decreasing exhaust or increasing supply flows lowers the null point. Opening doors below the null point introduces more air into the enclosure, which is comparable to increasing the supply flow and in turn lowering the null point. Opening a felt-loading door, above the null point, is equivalent to increasing the exhaust flow rate and raising the null point, even though hot and humid air would be “dumped” into the machine room.

Ventilation methods (3,4)

Four primary methods of ventilation are: mixed ventilation (dilution), unidirectional ventilation (piston airflow), displacement ventilation (passive thermal displacement), and localized ventilation (spot cooling). Displacement ventilation is the recommended method for paper machine building ventilation, with local ventilation applied to isolated areas.

General guidelines

1. Capture heat and water vapor as close to its source as possible because it will require less exhaust air flow than diluting it later.
2. Minimize the amount of air exhausted to reduce energy costs.
3. Move air from areas of low heat and water vapor concentrations to areas of high heat and water vapor concentrations: dry-end-to-wet-end and tending-side-to-drive-side. Introduce air into the building such that it removes as much heat and water vapor as practical before being exhausted.
4. A balance of supply and exhaust systems is required for either any ventilation system to function as designed.
5. General ventilation should primarily be used for comfort control, with water vapor control usually a secondary consideration. Dilution ventilation reduces overall water vapor concentration and temperature.
6. Use make-up air for personnel ventilation only.
7. Supply air should have sufficient volume and heat to prevent condensate and fog from forming.
8. Displace heat and water vapor from operating personnel zones with large quantities of make-up air. Distribute air directly to work zone (below 10 feet) to provide effective dilution ventilation. Avoid high velocity discharges, which entrain warm and humid air streams.
9. Care should be taken to avoid unintentional short-circuiting.
10. The exhaust discharge, whether local or general, should be directed so as to reduce the possibility of reentry. Exhaust discharges should be located away from windows and air intakes.
11. Avoid locating ventilation ducts in the upper building levels unless insulated.
12. Perform regular maintenance on ventilation equipment and systems to ensure optimum performance.
13. Test ventilation systems periodically to ensure they continue to operate as designed.

System description and dimensioning

Exhaust systems

The first priority of a good ventilation system is to capture heat and vapor at the source. Paper machine room ventilation systems should include:

- Forming section exhaust
- Dryer section hood exhaust
- Saveall exhaust
- Pulper exhaust
- Building exhaust
 - Wet end false ceiling
 - Size press and coater false ceilings
 - Roof exhaust

Forming section exhaust

Forming section exhaust systems contain and exhaust water vapor from between and below the forming wire.