

Above ground flat bottomed storage tanks: A guide to inspection maintenance and repair

Publication 159

Edition 5

Copyright © 2017 The Engineering Equipment and Materials Users Association
A company limited by guarantee. Registered in England. Company number 477838.

ISBN 978-0-85931-227-1

Imprint reference 08-2018 (including Amendment Sheet 1)
First published 09-2017

Registered and Trading Address:
EEMUA, Second Floor, 16 Black Friars Lane, London EC4V 6EB
Telephone: +44 (0)20 7488 0801
Email: sales@eemua.org
Website: www.eemua.org



Engineering Equipment and Materials Users Association

About EEMUA

The Engineering Equipment and Materials Users Association is usually known by its initials, EEMUA. EEMUA is governed by a Council of members. This Council is responsible for the policies, financing, membership, and strategy of the Association. Any organisation that is a substantial user or purchaser of engineering products may apply to become a member of EEMUA. Membership is subject to the approval of Council.

EEMUA Aims

EEMUA aims to improve the safety, environmental and operating performance of industrial facilities in the most cost-effective way, pursuing and promoting leadership in industrial asset management by sharing engineering experiences and expertise, and by the active, enlightened promotion of the distinct interests of users of engineering products. These aims are achieved by various means, including:

- Providing the organisation within which networking, information sharing and collaboration among users on non-competitive technical matters can take place.
- Influencing the way written regulations are interpreted and applied in practice.
- Promoting and presenting members' views, and encouraging the application of good sound engineering practices.
- Developing user guides, specifications, training and competency schemes.
- Facilitating members' participation in national and international standards making.
- Influencing relevant national and European legislation and regulation.

The income and resources of EEMUA are applied solely towards the promotion of the aims of the Association. No profit is transferred by way of dividend, bonus or otherwise to members. The work of the Association is mainly carried out by members' representatives on EEMUA Technical Committees, Working Groups, and Forums, supported by EEMUA staff.

Incorporation, Membership and Other Information

For the purposes of conducting its business, EEMUA is incorporated in England and Wales as a company, limited by guarantee, not having share capital. All usual aspects of company management and business administration are dealt with by the EEMUA Executive Director, including policy implementation and leadership of the Executive team (the staff).

A list of EEMUA publications for sale is given at the end of this Publication. The full list is also on the Association's website, including details of on-line shopping facilities.

To enquire about corporate Membership, write to enquiries@eemua.org or call +44 (0)20 7488 0801.

About this Publication

Legal Aspects

All rights, title and interest in this Publication belong to EEMUA. All rights are reserved. No part of this Publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means: electronic, mechanical, photocopying, recording or other, without the express prior written agreement of the EEMUA Executive Director. Infringement of copyright is illegal and also reduces the Association's income thereby jeopardising its ability to fund the production of future publications.

It has been assumed in the preparation of this Publication that: the user ensures selection of those parts of its contents appropriate to the intended application; and that such selection and application is correctly carried out by appropriately qualified and competent persons for whose guidance this Publication has been prepared. EEMUA and the individual members of the Work Group that prepared this EEMUA publication do not, and indeed cannot, make any representation or give any warranty or guarantee in connection with material contained herein. EEMUA and the individual members of the Work Group that prepared this EEMUA Publication expressly disclaim any liability or responsibility for damage or loss resulting from the use or reliance on this Publication. Any recommendations contained herein are based on the most authoritative information available at the time of writing and on current good engineering practice, but it is essential for the user to take account of pertinent subsequent developments and/or legislation.

Any person who encounters an inaccuracy or ambiguity when making use of this Publication is asked to notify EEMUA without delay so that the matter may be investigated and appropriate action taken.

Consultation and Feedback

EEMUA encourages constructive comments on this Publication from both Members of the Association and others.

Comments should be sent on the standard feedback form, a copy of which is provided towards the end of this Publication. An electronic version of the feedback form is available from EEMUA:

e-mail your request for a copy to:
enquiries@eemua.org

or telephone your request to:
+44 (0)20 7488 0801

or download the form from the EEMUA website at:
www.eemua.org.

Submit comments by e-mail (preferred) or post.

Comments are considered by the relevant EEMUA Technical Committees and may be incorporated in future editions of this Publication. New editions are publicised on the EEMUA website.

Contents

1 Introduction and scope.....	1
1.1 Introduction.....	1
1.2 Scope.....	2
1.3 Codes and history.....	2
1.4 Definitions and Abbreviations	3
2 Tanks and their components: Terminology and materials of construction.....	5
2.1 Tank components.....	5
2.2 Glossary of terms.....	7
2.3 Types of storage tanks	9
2.3.1 Standard atmospheric storage tanks.....	9
2.4 Materials.....	16
2.4.1 Ambient conventional storage tanks	16
3 Degradation mechanisms and failure modes	17
3.1 General corrosion	17
3.2 Tank settlement and consequential problems.....	18
3.3 Structural failure and/or failure of tank components/appendages.....	18
3.4 Low Cycle Fatigue failure mechanism.....	19
3.4.1 Storage tanks can be subject to cyclic stresses	19
3.4.2 Bottom-to-shell connection.....	20
3.4.3 Floating roofs	20
3.4.4 Articulated pipe of roof drain systems.....	20
3.5 Combination of degradation mechanisms and other influences.....	20
3.6 Microbial Induced Corrosion (MIC).....	21
4 Corrosion of tanks	23
4.1 General	23
4.2 Types of corrosion	23
4.2.1 Uniform corrosion	24
4.2.2 Pitting corrosion.....	24
4.2.3 Crevice / under deposit corrosion.....	25
4.2.4 Galvanic corrosion.....	27
4.2.5 Stress corrosion cracking (SCC).....	28
4.2.6 Microbiologically induced corrosion (MIC)	28

4.3 Corrosion rates	29
4.4 Bottom plates	31
4.4.1 Failure modes	31
4.4.2 Bottom plate soil side corrosion.....	31
4.4.3 Bottom plate product side corrosion.....	33
4.5 Shell plates (internal and external)	34
4.6 Roof plates.....	37
4.6.1 Fixed roofs including roof support structure	37
4.6.2 Floating roofs including supporting legs.....	39
4.7 Corrosion Under Insulation (CUI).....	40
4.8 Corrosion of stubs and appendages	44
5 General inspection techniques and interpretation of inspection data.....	45
5.1 References	45
5.1.1 Inspection and maintenance	45
5.1.2 Assessing the tank norm or standard.....	49
5.1.3 Fit-for-purpose analysis of storage tanks:	52
5.2 Inspection	52
5.2.1 General.....	52
5.2.2 Operator observations	54
5.2.3 Routine and detailed visual inspections.....	55
5.2.4 In-service inspection (non-intrusive)	56
5.2.5 Out-of-service inspection.....	57
5.2.6 Safety considerations during inspection.....	58
5.3 Ultrasonic thickness measurements	59
5.3.1 General	59
5.3.2 Phased Array Ultrasonic Testing (PA UT).....	59
5.3.3 Alternating Current Field Measurement (ACFM).....	61
5.3.4 Tank shell measurement	63
5.3.5 Tank bottom measurement	65
5.3.6 Tank roof measurement	67
5.3.7 Measurement of nozzles and manhole neck plates.....	69
5.4 Evaluation of shell inspection data.....	71
6 Tank foundations	75
6.1 General	75
6.1.1 Introduction	75
6.1.2 Failure modes of tank foundations.....	76
6.2 Soil settlement	76
6.2.1 Settlement under loads.....	76
6.2.2 Consolidated settlement	76

6.3 Effects of soil settlement	77
6.3.1 Even (uniform) settlement.....	77
6.3.2 Tank shell settlement into the foundation.....	77
6.3.3 Difference in soil settlement between centre and periphery of the tank.....	78
6.3.4 Uneven settlement	81
6.3.5 Edge settlement	82
6.3.6 Planar tilt	84
6.3.7 Differential shell settlement around circumference	84
6.3.8 Evaluation and measurements for shell out of roundness	86
6.4 Leakage	86
6.5 Maximum tolerances and limits for settlement and out-of-verticality of tank shell	87
6.5.1 Planar tilt/out-of-verticality	87
6.5.2 Edge Settlement.....	91
6.5.3 Differential settlement.....	92
6.5.4 Sagging/centre-to-edge bottom settlement.....	95
6.5.5 Bottom ripples	96
6.6 Re-levelling of tank foundations	96
6.7 Tank lifting operations	97
6.7.1 Preliminaries	97
6.7.2 Tank lifting	98
6.7.3 Wind loading.....	98
6.7.4 Safety measures against wind damage	99
6.8 Repair/modification methods - some typical examples	100
7 Tank bottoms (with or without annular plates).....	101
7.1 General	101
7.2 Introduction.....	101
7.3 Determination of floor thickness and condition.....	102
7.4 Rejection limits.....	105
7.4.1 Floor area.....	105
7.4.2 Annular area.....	108
7.4.3 Annular projection	108
7.5 Bulges and depressions in tank bottom plates	113
7.6 Cathodic protection	114
7.7 Repair/modification methods - some typical examples	114
8 Tank shells	115
8.1 General	115
8.2 Determination of effective shell plate thickness and condition	116
8.3 Rejection limits for shell plates	117
8.3.1 Liquid Load and vapour pressure.....	117
8.3.2 Wind and vacuum loads	120

8.3.3 Roof loads.....	122
8.3.4 Pit corrosion assessment	123
8.4 Minimum thickness calculations for riveted tank shells.....	123
8.5 Top wind girder and intermediate wind stiffeners.....	124
8.5.1 Shell top wind girders	124
8.5.2 Intermediate wind stiffeners	125
8.6 Buckling problems of tank shells and top wind girders	128
8.6.1 Buckling problems of tank shells.....	128
8.6.2 Shell top wind girders	131
8.7 Manholes, nozzles and connecting piping	132
8.7.1 Shell manholes and nozzles	132
8.7.2 Connecting piping.....	133
8.7.3 Rejection limits shell nozzles.....	134
8.8 Clean-out doors and openings.....	135
8.8.1 Clean-out doors.....	135
8.8.2 Clean-out openings.....	136
8.9 Earthing	137
8.10 Repair/modification methods - some typical examples.....	138
9 Tank roofs - general	141
9.1 Introduction.....	141
9.2 Determination of roof plate thickness and condition	141
10 Fixed roofs (cone roofs and dome roofs).....	143
10.1 General.....	143
10.2 Roof manholes and nozzles	144
10.3 Roof vents (ventilation of tanks) and emergency relief vents	145
10.3.1 The functioning of roof vents	145
10.3.2 Venting requirements for fixed roof tanks.....	146
10.3.3 Inspection and maintenance of roof vents.....	148
10.3.4 Possible ventilation problems	152
10.3.5 Flame arresters	154
10.3.6 Pressure test of the fixed roof	155
10.3.7 Temporary closure of openings in open vents or pressure–vacuum valves during operation	156
10.3.8 Protection against static electricity and lightning	156
10.4 Column supported roofs	156
10.4.1 Internal Inspection and repair.....	157
10.4.2 Tank jacking or lifting.....	157
10.4.3 Column design	158
10.5 Membrane (self-supporting) roof.....	158

10.6 Degradation limits for fixed roofs.....	158
10.6.1 Supported fixed roof.....	159
10.6.2 Roof supporting structure.....	161
10.6.3 Self-supporting fixed roof	161
10.7 Fitness for service assessment.....	161
10.8 Internal Floating Covers (IFCs).....	163
10.9 Repair/modification methods	166
11 Floating roofs	169
11.1 Types.....	169
11.1.1 General.....	169
11.1.2 Pontoon type floating roofs.....	170
11.1.3 Double-deck floating roofs.....	171
11.1.4 Special roofs such as buoy type and radially reinforced roofs	172
11.2 Degradation limits.....	173
11.2.1 General corrosion.....	173
11.2.2 Pit corrosion	174
11.3 Equipment on External floating roofs.....	175
11.3.1 Roof drains	175
11.3.2 Floating roof seals.....	180
11.3.3 Roof support legs.....	191
11.3.4 Floating roof venting.....	193
11.3.5 Rolling ladders	194
11.3.6 Earthing of floating roofs.....	196
11.4 Guidelines for the operation of floating roofs.....	196
11.4.1 Introduction	196
11.4.2 Before the roof is taken into service	196
11.4.3 During the first month of operation	196
11.4.4 During operation.....	197
11.4.5 Before landing the roof.....	198
11.4.6 Roof standing on its supports.....	198
11.4.7 Recommended filling rates for floating roof tanks	198
11.4.8 Ballooning of single-deck floating roof	199
11.5 Possible problems with EFR buoyancy.....	201
11.5.1 Leaking pontoon compartments.....	201
11.5.2 Cracking in centre deck due to wind loading.....	201
11.5.3 Out-of-roundness tolerances	201
11.6 Repair/modification methods	203
11.6.1 Overplating.....	204

11.7 Snow load on EFR.....	204
11.7.1 Inspection history	204
11.7.2 Removal of the snow	204
11.7.3 Operation of the tank	205
11.8 Aluminium dome roofs	205
12 Tank appendages.....	207
12.1 Shell and roof nozzles.....	207
12.2 Floating suction lines.....	209
12.2.1 Design.....	209
12.2.2 Operational experiences.....	209
12.2.3 Inspection.....	210
12.3 Ladders, stairways, platforms/railings and lighting.....	210
12.4 Side entry mixers.....	211
12.5 Tank instrumentation	212
12.5.1 General/records	212
12.5.2 Instrument and component failure due to external corrosion.....	213
12.5.3 Electronic instruments	213
12.5.4 Tank cooling and fire protection system	214
13 Tank coatings	215
13.1 Introduction	215
13.2 External coating systems.....	215
13.2.1 General.....	215
13.2.2 Bottom	216
13.2.3 Shell and roof	216
13.3 Internal coating systems.....	216
13.3.1 General.....	216
13.3.2 Bottom	218
13.3.3 Shell and Roof	219
13.4 Repair/modification methods - some typical examples.....	219
14 Tank insulation.....	221
15 Hydrotesting	225
15.1 General.....	225
15.2 Hydrostatic testing after repair, re-siting and modification.....	227
15.2.1 Full hydrostatic test.....	227
15.2.2 Partial hydrostatic test.....	227
15.2.3 No hydrostatic test.....	227
15.2.4 No hydrostatic test (exemptions)	228

15.3 Requirements for hydrotesting.....	230
15.3.1 Pipe connections.....	230
15.3.2 Water quality.....	230
15.3.3 Test temperature.....	231
15.3.4 Filling rates.....	231
15.3.5 Maximum filling height	233
15.3.6 Holding time.....	233
15.3.7 Emptying after hydrotest	234
15.4 Settlement monitoring.....	234
16 Re-siting of vertical tanks.....	237
16.1 General.....	237
16.2 Moving using a crane with spreader beam.....	237
16.3 Moving on rail tracks.....	237
16.4 Moving by air-cushion method	238
16.5 Moving by floating.....	238
16.6 Moving by self-propelled trailers	239
16.7 Testing requirements.....	239
17 Probabilistic Preventive Maintenance (PPM) for tanks.....	241
17.1 Introduction.....	241
17.2 Inspection and Maintenance based on risk.....	242
17.2.1 Introduction to risk management.....	242
17.2.2 Asset management plan.....	242
17.2.3 Maintenance Maturity	243
17.2.4 Life Cycle Costing.....	245
17.2.5 Plan-Do-Check-Act Cycle of Maintenance	247
17.2.6 Set up (Plan)	248
17.2.7 Execution (Do)	248
17.2.8 Evaluation (Check).....	248
17.2.9 Closing the loop (Act/Adjust)	248
17.3 Introduction to PPM.....	249
17.4 Risk Based Inspection (RBI)	250
17.4.1 Introduction	250
17.4.2 Methodology.....	252
17.4.3 Probability of a specific failure.....	253
17.4.4 Consequences of a specific failure	254
17.4.5 Risk rating	255
17.4.6 Determination of next required inspection date.....	256
17.4.7 RBI, THE STEPS.....	259
17.4.8 The steps 5 and 6: Calculation of interval before next inspection	261
17.4.9 Asset management plans.....	262

17.5 Reliability Centred Maintenance (RCM)	263
17.5.1 Tank facility Maintenance Approach	263
17.5.2 Set up Asset Register.....	264
17.5.3 Failure Modes & Effect (Analysis) FMEA.....	267
17.5.4 Criticality (Analysis)	270
17.5.5 Risk mitigation	273
17.5.6 Defining mitigating actions	273
17.5.7 Monitoring strategy.....	281
17.5.8 Reliability & Availability.....	282
17.5.9 Maintenance Plan	285
17.5.10 Monitoring maintenance performance.....	286
17.6 PPM process.....	287
17.7 PPM implementation.....	292
17.7.1 Introduction	292
17.7.2 Resources.....	293
17.7.3 Minimum requirements for PPM.....	293
17.7.4 Involvement of regulatory bodies and competent authorities.....	295
18 Mothballing	297
18.1 Introduction	297
18.1.1 Safety precautions.....	298
18.2 Protection Procedure.....	298
18.2.1 6 to 12 Months	298
18.2.2 12 to 18 Months.....	298
18.2.3 More than 18 Months.....	298
18.2.4 Floating tank roofs.....	298
18.3 Reducing the Risk of Internal Degradation	299
18.3.1 Instrument Air Conditions.....	299
18.3.2 Inerting the Tank	299
18.4 Reducing the Risk of External Corrosion.....	300
Appendix A Tank assessment, records and reports.....	303
A.1 Tank records.....	303
A.2 Minimum allowable thickness and shell-to-edge projection of annular plates.....	305
Appendix B Inspection checklists and frequencies	307
B.1 Inspection frequencies	307
B.2 Tank inspection checklist.....	312
B.3 Example NDT inspection sheets	328